

INSTALLATION AND MAINTENANCE MANUAL

VORTAB™ Flow Conditioner Models VIS, VMR, VSR and VFK

Doc. No. 06EN003269

Rev. A

Notice of Proprietary Rights

This document contains confidential technical data, including trade secrets and proprietary information which are the property of Vortab™ and protected by United States Patent Numbers 4,929,088 and 4,981,386.

Disclosure of this data to you is expressly conditioned upon your assent that its use is limited to use within your company only (and does not include manufacture or processing uses). Any other use is strictly prohibited without the prior written consent of Vortab.

Protected by United States and other Patents

© *Copyright 1996 Vortab™*
All Rights Reserved

CUSTOMER COMMITMENT PLEDGE

We will work closely with our customers to provide the best products and service

- at a competitive value
- on time
- with unquestioned support

in full compliance with our *COMPLETE CUSTOMER COMMITMENT*.

COMMITMENT TO QUALITY

In keeping with the overall commitment of management and employees of Vortab to Total Quality Management, the Publications Department expresses its pledge and mission to you, our customer:

“To support the creation and publication of world-class technical material which is technically accurate and practical, concise and user-friendly, attractive and professional in appearance, and consistent in form, format, content, and style.”

QUALITY IMPROVEMENT

We appreciate your comments and suggestions which support our effort to constantly improve our product and services. Please address comments and suggestions to your nearest field representative or in-house technical support representative. Thank you.

VORTAB TECHNICAL PUBLICATIONS DEPARTMENT

CUSTOMER SERVICE AND TECHNICAL SUPPORT

Vortab provides full in-house technical support for our products 7 a.m. to 5 p.m. PST, Monday through Friday (excepting holidays and an annual plant closure between Christmas and New Year's day). Also, additional technical representation is provided by Vortab field representatives.

By Mail

Vortab
1755 La Costa Meadows Dr.
San Marcos, CA 92069
Attn: Customer Service Department

By Phone

Contact the Vortab regional representative in your area. If you are unable to contact the field representative or are unable to satisfactorily resolve an issue, contact the Vortab Customer Service Department toll free at (800) 854-9959.

By Fax

To describe a situation in a more graphic or pictorial manner, send your regional representative a fax. The fax should include your phone and fax number. Again Vortab is available through facsimile if you have exhausted your possibilities with the authorized factory representative. Our fax number is (619) 736-6250; it is available 7 days a week, 24 hours a day.

Appendix A contains a detailed explanation of the Vortab customer service policy on returns, adjustments, in-field or factory repair, in- or out-of-warranty.

REVISIONS

REV.	DESCRIPTION	DATE	AUTHOR
N/C	Initial Release.	2/29/96	R. Sanders
A	Totally revised manual to comply with current engineering.	11/7/96	R. Sanders

Contents

Chapter 1 - General Product Information	
Description	1 - 1
Theory of Operation	1 - 1
Technical Specifications	1 - 2
Chapter 2 - Installation	
Receiving and Inspection	2 - 1
Packing, Shipping and Returns	2 - 1
Vortab Insertion Sleeve Flow Conditioner Installation	2 - 1
Tack Weld Mounting	2 - 1
Retaining Wafer Mounting	2 - 2
Vortab Meter Run Flow Conditioner Installation	2 - 3
Butt Weld Mounting	2 - 3
Flange Mounting	2 - 3
Vortab Short Run Flow Conditioner Installation	2 - 4
Butt Weld Mounting	2 - 4
Flange Mounting	2 - 4
Vortab Field Kit Flow Conditioner Installation	2 - 5
Process Pipe Preparation	2 - 5
Tab Placement Calculation	2 - 5
Welding Procedures	2 - 5
Chapter 3 - Maintenance	
General Maintenance	3 - 1
VIS, VMR, VSR AND VFK Maintenance	3 - 1
Appendix A - Customer Service	
Policies and Procedures	A - 1

Figures

1-1 Typical Vortab Installation	1 - 1
2-1 Orientation of VIS in Process Pipe or Duct	2 - 1
2-2 Typical Tack Weld Installation of a VIS	2 - 2
2-3 Typical Retaining Wafer Mounting of a VIS	2 - 2
2-4 Typical Butt Weld Mounting of a VMR	2 - 3
2-5 Typical Flange Mounting of a VMR	2 - 3
2-6 Typical Butt Weld Mounting of a VSR	2 - 4
2-7 Typical Flange Mounting of a VSR	2 - 4
2-8 Orientation of VFK in Process Pipe or Duct	2 - 5
2-9 VFK Assembly Drawing	2 - 6
2-10 Radial Placement	2 - 6

Table

2-1 Depth Placement Dimensions	2 - 5
--------------------------------------	-------

Symbol

The following symbol is used in the manual to draw attention to items or procedures that require special notice or care.



Warning: Warns of possible **personal danger** to those handling the equipment.

