

INSTALLATION, OPERATION & MAINTENANCE MANUAL

Model FR78B Fast Response Flow Switch/Monitor

Doc. No. 06EN003281

Rev. -

Notice of Proprietary Rights

This document contains confidential technical data, including trade secrets and proprietary information which are the property of Fluid Components Intl (FCI).

Disclosure of this data to you is expressly conditioned upon your assent that its use is limited to use within your company only (and does not include manufacture or processing uses). Any other use is strictly prohibited without the prior written consent of FCI.

*© Copyright 1998 Fluid Components Intl
a limited liability company
All Rights Reserved*

CUSTOMER COMMITMENT PLEDGE

We will work closely with our customers to provide the best products and service

- at a competitive value
- on time
- with unquestioned support

in full compliance with our *COMPLETE CUSTOMER COMMITMENT*.

COMMITMENT TO QUALITY

In keeping with the overall commitment of management and employees of Fluid Components Intl to Total Quality Management, the Manual Committee (Quality Circle) expresses its pledge and mission to you, our customer:

“To support the creation and publication of world-class technical material which is technically accurate and practical, concise and user-friendly, attractive and professional in appearance, and consistent in form, format, content, and style.”

QUALITY IMPROVEMENT

We appreciate your comments and suggestions which support our effort to constantly improve our product and services. Please address comments and suggestions to your nearest field representative or in-house technical support representative. Thank you.

FCI Manual Team

CUSTOMER SERVICE/TECHNICAL SUPPORT

FCI provides full in-house technical support for our products 7 a.m. to 5 p.m. PST, Monday through Friday (excepting holidays and an annual plant closure between Christmas and New Year's day). Also, additional technical representation is provided by FCI field representatives. Before contacting one of our field or in-house representatives, please ensure that you have performed the troubleshooting techniques outlined in this document.

By Mail

Fluid Components Intl
1755 La Costa Meadows Dr.
San Marcos, CA 92069
Attn: Customer Service Department

By Phone

Contact the FCI regional representative in your area. If you are unable to contact the field representative or are unable to satisfactorily resolve the situation, contact the FCI Customer Service Department at 1 (800) 854-1993 toll free.

By Fax

To describe your problems in a more graphic or pictorial manner, send your regional representative a fax. The fax should include your phone and fax number. Again FCI is available through facsimile if you have exhausted your possibilities with the authorized factory representative. Our fax number is (760) 736-6250; it is available 7 days a week, 24 hours a day.

International Support

For product information or product support outside the contiguous United States, Alaska, or Hawaii, contact your country's FCI International Representative or the one nearest to you. See list on following pages.

Appendix C contains a detailed explanation of the FCI customer service policy on returns, adjustments, in-field or factory repair, in- or out-of-warranty.

Reserved for Domestic Rep Map

Reserved for International Rep Map

Contents

Chapter 1 - General Information	
Description	1 - 1
Flow Element	1 - 1
Control Circuit	1 - 1
Specifications	1 - 2
Chapter 2 - Installation	
Receiving/Inspection	2 - 1
Packing/Shipping>Returns	2 - 1
Factory Calibration Note	2 - 1
Required Materials	2 - 1
Pre-Installation	2 - 1
Verify Serial Numbers	2 - 1
Verify Installation Location	2 - 2
Flow Element Installation	2 - 2
Wiring Installation	2 - 2
Conduit Routing	2 - 2
Minimum Wire Size	2 - 2
Cable Connections	2 - 2
Chapter 3 - Operation	
Factory Calibrations	3 - 1
Field Calibrations for Flow Applications	3 - 1
Alarm Set Point Adjustments By Observation or By Measurement	3 - 1
Alarm 1 Set Point Procedure for 5181 Control Circuit	3 - 1
Creating a Calibration Curve Using an FM71 Calibrator	3 - 5
Chapter 4 - Maintenance	
Maintenance	4 - 1
Alarm Set Point Verification	4 - 1
Enclosure	4 - 1
Electrical Wiring	4 - 1
Electrical Connections	4 - 1
Process Connection	4 - 1
Chapter 5 - Troubleshooting	
Tools Needed	5 - 1
Quick Check	5 - 1
Non-maintenance Observations	5 - 1
Check Serial Numbers	5 - 1
Check Input Power	5 - 1
Check the Instrument Installation	5 - 1
Check for Moisture	5 - 1
Check Application Design Requirements	5 - 2
Control Circuit Dash Number Specification	5 - 2
Verification of Flow Element Resistance	5 - 2
Verification of Flow Element Voltage	5 - 3
Spares	5 - 3
Defective Parts	5 - 3
Customer Service	5 - 3
Appendix A - Drawings	
Appendix B - Glossary	
Appendix C - Customer Service	

Figures

1-1	FR78B Fast Response Flow Switch/Monitor	1 - 1
3-1	Setting Alarm Switch Points	3 - 2
3-1	Control Circuit 5181 Outline Drawing	3 - 2
5-1	Troubleshooting Flow Chart	5 - 4
A-1	Flow Element Dimensional View	A - 1
A-2	Wiring Diagram	A - 1
A-3	5181 Control Circuit	A - 2
A-4	Optional Remote Enclosure NEMA Type 4	A - 2

Tables

2-1	Interconnecting Cable Size	2 - 2
5-1	Flow Element Resistances in Ohms	5 - 2
5-2	Remote Flow Element Resistances in Ohms	5 - 3
5-3	Flow Element Voltages	5 - 3

Symbols

The following symbols are used throughout the manual to draw attention to items or procedures that require special notice or care.



Warning: Warns of possible **personal danger** to those handling the equipment.



Caution: Cautions against possible **equipment damage**.



Note: Contains important information.